

65 First Flight Drive, Auburn Maine, 04210

www.strainrite.com

Thank you for purchasing this high quality filter housing. This pressure vessel has been manufactured from the highest quality materials by skilled craftsmen. Each vessel undergoes rigorous testing prior to shipping to ensure your satisfaction.

1. **General Requirements and Safety information**
2. **Operation & Installation**
3. **Parts list**

1) **General Requirements:**

A) **Safety Pressure Relief:**

- 1) We strongly recommend that a pressure relief valve be used to prevent over-pressurizing the vessel. Over-pressurizing could cause serious damage to both the unit and the operator. The installation of pressure relief valve(s) is the responsibility of the owner/operator. The allowable working pressure and temperature(s) are marked on the vessel's name plate. The pressure relief should be installed in a location so that it is not isolated from the vessel by process stop valves.

B) **Management System Responsibilities**

- 1) The user has the responsibility to establish and maintain a management system that ensures the vessel is not operated without over pressure protection including but not limited to:
 - A) Establishing the pressure relief philosophy and the administrative controls requirements.
 - B) Establishing procedures to ensure that the equipment is adequately protected against over pressure.
 - C) Ensuring that authorization to operate identified valves is clear and that personnel are adequately trained for this task.
 - D) Establishing periodical safety inspections.

- C) **Pressure indicating device:** Device range should be graduated with an upper limit that is neither less than 1.25 times the set pressure nor more than twice the maximum allowable working pressure of the vessel.
- D) **Registration:** Depending on size, pressure, and contents, local laws may require the pressure vessel to be registered within 30 days of installation and be subject to periodical inspections by the governing authority.
- E) **Electrical Devices** attached on or near vessels require ground fault power supply and may require hazard class ratings.
- F) **Venting** may release condensed vapors into the air. Operator exposure and ignition sources including static may need to be controlled.

2) Operation & Installation – Servicing Instructions

A) **Warning: Relieve All Pressure Before Servicing Vessel.**

- B) Once you have decided where your unit will be located, the legs should be secured to the floor with the appropriate fasteners and the piping connections made. Care should be taken when the piping is installed so that you do not place piping loads on the vessel. The design of piping supports and expansion joints are the customer's responsibility.

C) **Warning: Do not loosen bolts while under pressure.**

- D) **Opening the vessel:** Upon receiving your new vessel housing, you will notice the band-clamp located on the cover. Unscrew the T-bolt far enough so that the latch swings away from the lid. The cover is now ready for removing. Once the cover is opened, you will see a basket inside. You will notice on the top rim of the vessel body an "O" ring. This gasket sits between the two metal surfaces of the cover and vessel body to prevent leakage.

Bag change-out: For best results, the filter bags should be changed when the differential pressure is between 15 to 25 pounds per square inch. The differential pressure can be calculated with the use of gauges connected to the inlet and outlet. The outlet pressure is subtracted from the inlet pressure. The result is the differential pressure. High differential pressures can damage the retainer basket and should be avoided. The basket supports the filter bag inserted into it. Filter bags are available in a wide variety styles and are sold separately. Remove the dirty filter bag and dispose of it according to proper company, local and federal requirements. The top ring of the filter bag should sit snugly inside a metal rim on the basket flange. The filter bag should be pressed down to the bottom of the basket with either, your hand and arm, or by using a long blunt instrument. Each time a new filter bag is installed it is important to ensure that the sides and bottom for the bag are against the basket.

- E) **Closing the vessel:** Check the O-ring on the top of the vessel body where the lid meets the vessel. Replace band-clamp and secure. With the cover secured, the vessel can be refilled and checked for any leakage around the gasket area. Once the vessel is checked and no leaks are found the vessel can be pressurized and returned to service.

- F) Valves should be operated slowly.

G) **Warning: Do not tighten bolts while under pressure.**

- H) **Prohibited service conditions:** Cyclic/pulsing pressure, non-compatible fluids, lethal service, highly corrosive fluids, Fluid Hammer.

No.	Description	Material	Part#
1	#4 Band Clamp	Stainless	150605
2	Cover Gasket	Buna*	150145
3	SRL 25 Basket	Stainless	353694
	SRL 50 Basket	Stainless	353696
4	Optional Stand	Carbon Steel	350701

*Gaskets are available in Buna, Fluoropolymer, EPDM, Silicone

